

# AE 760AA: Micromechanics and multiscale modeling

## Lecture 7 - Physical measurements

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering

February 13, 2019

## schedule

- Feb 13 - Physical measurements (HW2 Due)
- Feb 18 - Variational Calculus
- Feb 20 - Variational Calculus
- Feb 25 - Bounds and Boundary Conditions

# outline

- review
- measuring  
orientation

# review

## checking transformations

- Follow the procedure **here**
- This gives a way to systematically check whether your rotations are correct
- You can check any coordinate transformation as long as you know the unit vectors of your primed coordinate system in the global coordinates

$$x = [Q^T]x'$$

## common homework errors

- Some people had rotations about an axis with zeros along the diagonal
- This is possible with successive rotations, but for a rotation about one of the three axes, you should always have one term along the diagonal equal to 1
- When calculating stiffness in Problem 2, most students had some unexpected behavior
- All four walls had same  $x_1$  component of fibers, you should have gotten  $C_{11}$  the same for all 4 walls
- $C_{22}$  or  $C_{33}$  should have also been equal to  $C_{11}$ , depending on the wall

# measuring orientation

## measuring orientation


- In micromechanics (and most places where multi-scale modeling would be used), measuring local orientations can be difficult
- For composites, these are some common techniques
  - Microscopy (some ambiguity in orientation tensor)
  - Serial sectioned microscopy (eliminates ambiguity, very expensive)
  - CT-scanning (only gives approximate measure)
  - Micro CT-scanning (only for very small parts)




## microscopy

- Cylindrical fiber intersects cutting plane at some angle
- After cutting and polishing, this leaves an ellipse
- By measuring the ellipse, we can calculate the angle between it and the cutting plane
- Microscopy can also be used to measure volume fraction, void content, and fiber spacing

# microscopy



# fiber in spherical coordinates






## fiber direction components

Component	Definition
$p_1$	$\sin \theta \cos \phi$
$p_2$	$\sin \theta \sin \phi$
$p_3$	$\cos \theta$

# measurements



## calculations

- We find the major ( $M$ ) and minor ( $m$ ) axes using

$$m = \sqrt{(x_3 - x_4)^2 + (y_3 - y_4)^2}$$

$$X = x_1 - x_2$$

$$Y = y_1 - y_2$$

$$M = \sqrt{X^2 + Y^2}$$



## orientation tensor


- We can now calculate angles using

$$\sin \phi = \frac{Y}{M} \cos \phi = \frac{X}{M} \cos \theta = \frac{m}{M} \sin \theta = \sqrt{1 - \frac{m^2}{M^2}}$$


# microscopy




# microscopy



# microscopy




# microscopy





# microscopy



## software

- If you have to do a lot of microscopy measurements, contact Dr. Sharma, he wrote an automated measurement tool
- Otherwise you can use **imageJ**



## microscopy

- Need to account for bias in measurement (more likely to see fibers coming out of plane)
- There is some ambiguity in fiber angle
- Fiber at  $(\phi, \theta)$  is not distinguishable from  $(\phi + \pi, \theta)$
- In the second-order orientation tensor, this affects  $a_{23}$  and  $a_{13}$

## serial sectioning

- Serial sectioning is a method where you continually polish a specimen after photographing it
- After photograph you grind and polish, then photograph and repeat
- Gives the full 3D state of orientation, but is difficult

## CT Scanning

- Even if a CT Scan cannot resolve down to fiber resolution, the gradient information can give an idea of fiber orientation
- This method is not very precise
- But it can view the full-field and detect many forms of damage without destroying a part
- At the micro-scale full orientation can be obtained, but this is not practical for large parts